





N O T E


THIS DRAWING AS AN INSTRUMENT OF SERVICE. IS THE PROPERTY OF R E S Y S T A AND AS SUCH MUST NOT BE REPRODUCED OR COPIED IN PART OR IN WHOLE WITHOUT THE PERMISSION OF THE AUTHOR.

BUTT JOINT HORIZONTAL CLADDING


	SPECIFICATION		SHEET CONTENT	SHEET SIZE	DRAWING NO.
	TYPICAI	DRAWING	ISOMETRIC VIEW	A3	BJHCD-01
			BLOW-UP DETAIL		טאוונט-עו
				DATE	REVISION
	CAD BY:	CHECKED BY:		21.07.22	0
	M.T.C.	C.R.E			










cladding boards at the ends, please consider Resysta Expansion.











Note:

Remove adhesive strip cover film. Center Hollow Cap on the end of the plank and apply with firm pressure all around the center supports.





## Note:

Be sure that all surfaces are clean and free of debris such as dust, dirt, oils and paints. Remove adhesive strip cover film. Center Hollow Cap on the end of the plank and apply with firm pressure all around the center supports.

