




N O T E

THIS DRAWING AS AN INSTRUMENT OF SERVICE. IS THE PROPERTY OF R E S Y S T A

AND AS SUCH MUST NOT BE REPRODUCED OR COPIED IN PART OR IN WHOLE WITHOUT THE PERMISSION OF THE AUTHOR.


ALUMINUM TRIM VERTICAL CLADDING DETAIL


SPECIFICATI	ION		SHEET CONTENT		SHEET SIZE	DRAWING NO.	CONTINENT
TY	TYPICAL DRAWING		ISOMETRIC VIEW		A3	ATVCD-01	RESYSTA
DETAIL			BLOW-UP DETAIL			ATVCD-VI	
					DATE	REVISION	IIC V
CAD BY:		CHECKED BY:	-		14.02.23	2	USA
I м	Τſ	CRF					





## Note:

**NO Trim** should be installed at each board abutment joint to cover the ends of the Resysta Wall Cladding Boards. This is for installation using 3 or more boards abutted end-to-end. When connecting wall cladding boards at the ends, please consider Resysta Expansion.









## Note:

Outside corner trim should be pre applied prior to installing wall cladding boards. The wall cladding board end that is inserted into the outside corner should be miter cut at a 45 degree angle to match up with the outside corner internal web. Follow the gap guide when installing the wall cladding board to allow for expansion and contraction within the outside corner trim

