



# DIMENSION LEGEND

Millimeter (mm)  
Inches (") / Foot (')

RESSJM10 J Mold  
Reverse RESSHTC10  
Hat Channel  
RESSJS10 Siding Starter  
J Strip  
Existing Wall



TOP VIEW



BLOW-UP  
ELEVATION



FRONT ELEVATION


RESCPH120612 Siding

RESCPSS25 Stainless  
Steel Screw


Reverse RESSHTC10  
Hat Channel

RESSJS10 Siding Starter  
J Strip


Existing Wall



FRONT ELEVATION



BLOW-UP  
ELEVATION



SECTION

Note:

## SUB-DETAIL ATVSD 1.1

SCALE  
0 100 500 1000

Aluminum starter strip is required to install the Resysta siding board. Attach the starter strip at the bottom of the battens following the fastener and spacing recommendations. The Resysta siding boards will hang 1/2" below the bottom of the starter strip therefore the starter strip should be attached accordingly as per the pre plan layout.

**Resysta**<sup>®</sup>  
THE BETTER WOOD

### NOTE

THIS DRAWING AS AN INSTRUMENT OF SERVICE, IS THE PROPERTY OF RESYSTA AND AS SUCH MUST NOT BE REPRODUCED OR COPIED IN PART OR IN WHOLE WITHOUT THE PERMISSION OF THE AUTHOR.

### TITLE

ALUMINUM TRIM  
HORIZONTAL SIDING  
SUB-DETAIL

### SPECIFICATION

TYPICAL DRAWING DETAIL

### SHEET CONTENT

ELEVATION

BLOW-UP DETAIL

SECTION

TOP VIEW

DRAWING NO.

ATHSD-02

DATE

08.08.22

CAD BY:


M.T.C.

CHECKED BY:

C.R.E.

# DIMENSION LEGEND

Millimeter (mm)  
Inches (") / Foot (')




BLOW - UP  
ELEVATION

RESSHM10 Siding H Mold

RESSHTC10 Hat Channel

Existing Wall

RESCPH120612 Siding



TOP VIEW



FRONT ELEVATION

## SUB-DETAIL ATVSD 1.2




RESSHM10 Siding H Mold

RESSHTC10 Hat Channel

Existing Wall

RESCPH120612 Siding



ISOMETRIC VIEW

Table 1.4 "Resysta Expansion"

Resysta Siding Board Gap Guide					
Temperature at Installation	Aluminum Trim Gap of Siding Boards				H-Channel Gap
	Below 30 OF	60 OF	90 OF	120 OF	
Amount for Siding Profile - Length of 12 ft.	7/16"	5/16"	3/16"	0"	1/4"

### Note :

An H-Channel should be installed at each board abutment joint to cover the ends of the Resysta siding board. This is a option for installations using 3 or more boards abutted end-to-end



### NOTE

THIS DRAWING AS AN INSTRUMENT OF SERVICE, IS THE PROPERTY OF RESYSTA AND AS SUCH MUST NOT BE REPRODUCED OR COPIED IN PART OR IN WHOLE WITHOUT THE PERMISSION OF THE AUTHOR.

### TITLE

ALUMINUM TRIM  
HORIZONTAL SIDING  
SUB-DETAIL

### SPECIFICATION

TYPICAL DRAWING DETAIL

### SHEET CONTENT

ELEVATION  
BLOW-UP DETAIL  
TOP VIEW  
ISOMETRIC VIEW

### DRAWING NO.

ATHSD-03

### DATE

08.08.22

### CAD BY:

M.T.C.


### CHECKED BY:

C.R.E.




# DIMENSION LEGEND

Millimeter (mm)  
Inches (") / Foot (')




BLOW-UP  
ISOMETRIC

RESCPH120612 Siding  
RESSIC10 Inside Corner Mold  
Gap\_Refer to Table 1.4  
Reverse RESSHTC10  
Hat Channel  
RESCSS25 Stainless  
Steel Screw  
Existing Wall



TOP VIEW



## SUB-DETAIL ATVSD 1.3

SCALE  
0 100 500 1000

Table 1.4 "Resysta Expansion"

Resysta Siding Board Gap Guide					
Temperature at Installation	Aluminum Trim Gap of Siding Boards				H-Channel Gap
	Below 30 OF	60 OF	90 OF	120 OF	
Amount for Siding Profile - Length of 12 ft.	7/16"	5/16"	3/16"	0"	1/4"

ISOMETRIC  
VIEW

### Note :

Inside corner trim should be pre-applied prior to installing siding boards. The starter strip for the first board should be installed butted against the corner trim, not overlapping the corner trim attachment. Follow the gap guide when installing the siding board to allow for expansion and contraction within the inside corner trim.



### NOTE

THIS DRAWING AS AN INSTRUMENT OF SERVICE, IS THE PROPERTY OF RESYSTA AND AS SUCH MUST NOT BE REPRODUCED OR COPIED IN PART OR IN WHOLE WITHOUT THE PERMISSION OF THE AUTHOR.

### TITLE

ALUMINUM TRIM  
HORIZONTAL SIDING  
SUB-DETAIL

### SPECIFICATION

TYPICAL DRAWING DETAIL

### SHEET CONTENT

ISOMETRIC VIEW  
BLOW-UP ISOMETRIC  
TOP VIEW

### DRAWING NO.

ATHSD-04

### DATE

08.08.22

### CAD BY:


M.T.C.

### CHECKED BY:

C.R.E

# DIMENSION LEGEND

Millimeter (mm)  
Inches (") / Foot (')



Existing Wall

Reverse RESSHTC10  
Hat Channel


RESCPH120612 Siding

Gap\_Refer to Table 1.4

RESSOC10 Outside Corner Mold


RESCPSS25 Stainless  
Steel Screw

TOP VIEW



ISOMETRIC VIEW

## SUB-DETAIL ATVSD 1.4



BLOW-UP ISOMETRIC

Table 1.4 "Resysta Expansion"

Resysta Siding Board Gap Guide					
Temperature at Installation	Aluminum Trim Gap of Siding Boards				H-Channel Gap
	Below 30 OF	60 OF	90 OF	120 OF	
Amount for Siding Profile - Length of 12 ft.	7/16"	5/16"	3/16"	0"	1/4"

### Note :

Outside corner trim should be pre applied prior to installing siding boards. The starter strip for the first board should be installed butted against the corner trim, not overlapping the corner trim attachment. The siding board end that is inserted into the outside corner should be miter cut at a 45 degree angle to match up with the outside corner internal web.



### NOTE

THIS DRAWING AS AN INSTRUMENT OF SERVICE, IS THE PROPERTY OF RESYSTA AND AS SUCH MUST NOT BE REPRODUCED OR COPIED IN PART OR IN WHOLE WITHOUT THE PERMISSION OF THE AUTHOR.

### TITLE

ALUMINUM TRIM  
HORIZONTAL SIDING  
SUB-DETAIL

### SPECIFICATION

TYPICAL DRAWING DETAIL

### SHEET CONTENT

ISOMETRIC VIEW  
BLOW-UP ISOMETRIC  
TOP VIEW

### DRAWING NO.

ATHSD-05

### DATE

08.08.22

### CAD BY:



M.T.C.

### CHECKED BY:


C.R.E




# DIMENSION LEGEND



TOP VIEW



ISOMETRIC VIEW



BLOW-UP ISOMETRIC

## SUB-DETAIL ATVSD 1.5




Table 1.4 "Resysta Expansion"

Resysta Siding Board Gap Guide					
	Aluminum Trim Gap of Siding Boards				H-Channel Gap
Temperature at Installation	Below 30 OF	60 OF	90 OF	120 OF	
Amount for Siding Profile - Length of 12 ft.	7/16"	5/16"	3/16"	0"	1/4"

### Note :

When a siding board in either a horizontal or vertical application terminates into a wall, eave, window, door etc. a J-channel should be used to cover the exposed end of the siding board. The J-channel should also be used along the bottom of a vertical installation. J-channel trim should be pre-applied prior to installing siding boards.



### NOTE

THIS DRAWING AS AN INSTRUMENT OF SERVICE, IS THE PROPERTY OF RESYSTA AND AS SUCH MUST NOT BE REPRODUCED OR COPIED IN PART OR IN WHOLE WITHOUT THE PERMISSION OF THE AUTHOR.

TITLE	SHEET CONTENT	
ALUMINUM TRIM HORIZONTAL SIDING SUB-DETAIL	ISOMETRIC VIEW	
	BLOW-UP ISOMETRIC	
	TOP VIEW	
SPECIFICATION	DRAWING NO.	DATE
TYPICAL DRAWING DETAIL	ATHSD-06	08.08.22
	CAD BY:	CHECKED BY:
	M.T.C.	C.R.E