




N O T E


THIS DRAWING AS AN INSTRUMENT OF SERVICE. IS THE PROPERTY OF R E S Y S T A


AND AS SUCH MUST NOT BE REPRODUCED OR COPIED IN PART OR IN WHOLE WITHOUT THE PERMISSION OF THE AUTHOR.

ALUMINUM TRIM VERTICAL SIDING DETAIL


	SPECIFICATION		SHEET CONTENT	SHEET SIZE	DRAWING NO.	CONTINENT
	TYPICAL DRAWING DETAIL		ISOMETRIC VIEW	A3	ATVSD-01	RESYSTA
			BLOW-UP DETAIL			
				DATE	REVISION	110 1
ļ	CAD BY:	CHECKED BY:		02.04.02	0	034
	МТС	CDE		03.01.23		









Inside corner trim should be pre-applied prior to installing siding boards. The starter strip for the first board should be installed butted against the corner trim, not overlapping the corner trim attachment. Follow the gap guide when installing the siding board to allow for expansion and contraction within the inside corner trim.






## Note:


Outside corner trim should be pre applied prior to installing siding boards. The starter strip for the first board should be installed butted against the corner trim, not overlapping the corner trim attachment The siding board end that is inserted into the outside corner should be miter cut at a 45 degree angle to match up with the outside corner internal web.






## Note:


When a siding board in either a horizontal or vertical application terminates into a wall, eave, window, door etc. a J-channel should be used to cover the exposed end of the siding board. The J-channel should also be used along the bottom of a vertical installation. J-channel trim should be pre-applied prior to installing siding boards.






## Note:

When a siding board in either a horizontal or vertical application terminates into a wall, eave, window, door etc. a J-channel should be used to cover the exposed end of the siding board. The J-channel should also be used along the bottom of a vertical installation. J-channel trim should be pre-applied prior to installing siding boards.





An H-Channel should be installed at each board abutment joint to cover the ends of the Resysta siding board. This is a option for installations using 3 or more boards abutted end-to-end

